




Command Description

The Move Line command enables you to select a line and move left or right a small amount without needing to copy and offset.



The screenshot shows the 'Move Line' dialog box with the following fields and controls:

- Line:** A selection field with a mouse cursor icon.
- Direction:** A dropdown menu currently set to 'Left'.
- Distance:** A text input field containing '0.002'.
- Show Line Direction Options:** A button to expand the direction options.
- Apply** and **Close** buttons at the bottom.

1. Click in the **Line** selection field and then in a graphic view select the line which you want to use to move.
2. Pick the **Direction** to move the line.
3. Enter the **Distance** in the box you want to move the line by.

The **Show Line Direction Options** is a short cut to changing the options for the direction arrows. See Show Line Direction Options Command for more details.

4. Click **Apply** to apply the changes and **Close** to when finished with the command pane.

Note: If the line being moved contains vertical segments which are 5mm or less in horizontal length then the segment will be pushed to make it 5mm horizontally in the direction of the previous line segment.